



32"– 34"
Height

Rattle leans to the left

6.5" from wall to edge of cup

Shift base 3" to the right or leave off first cup